

TORCTOOL

TOOL MODEL: TTX-11

PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	FT. LBS.	TORQUE IN		PRESSURE IN BAR
		KGM	NM	
1500	1580	219	2142	104
1600	1689	234	2290	110
1800	1906	264	2584	124
2000	2124	294	2879	138
2200	2340	324	3172	152
2400	2556	354	3465	165
2600	2773	383	3759	179
2800	2989	413	4052	193
3000	3205	443	4345	207
3200	3424	473	4641	220
3400	3642	504	4937	234
3600	3860	534	5233	248
3800	4078	564	5528	262
4000	4296	594	5824	276
4200	4517	625	6124	290
4400	4738	655	6423	303
4600	4959	686	6723	317
4800	5180	716	7022	331
5000	5401	747	7321	345
5200	5623	778	7622	358
5400	5844	808	7923	372
5600	6066	839	8223	386
5800	6288	870	8524	400
6000	6510	900	8825	414
6200	6737	932	9132	427
6400	6964	963	9440	441
6600	7191	994	9748	455
6800	7418	1026	10055	468
7000	7645	1057	10363	482
7200	7878	1090	10680	496
7400	8112	1122	10997	510
7600	8346	1154	11314	524
7800	8580	1187	11631	538
8000	8814	1219	11948	552
8200	9059	1253	12280	565
8400	9304	1287	12612	579
8600	9549	1321	12945	593
8800	9794	1355	13277	607
9000	10039	1388	13609	620
9200	10257	1418	13904	634
9400	10474	1449	14198	648
9600	10691	1479	14493	662
9800	10909	1509	14788	676
10000	11126	1539	15083	690