

# TORCTOOL

## TOOL MODEL: TTZ-8 W 215 HEX LINK PRESSURE/TORQUE CONVERSION CHART

### Standard Torque Chart

PRESSURE IN PSI	FT. LBS.	TORQUE IN		PRESSURE IN BAR
		KGM	NM	
1500	1292	179	1751	104
1600	1376	190	1865	110
1800	1544	213	2093	124
2000	1712	237	2320	138
2200	1891	261	2563	152
2400	2070	286	2806	165
2600	2249	311	3048	179
2800	2428	336	3291	193
3000	2607	361	3534	207
3200	2785	385	3775	220
3400	2963	410	4017	234
3600	3142	434	4259	248
3800	3320	459	4501	262
4000	3498	484	4742	276
4200	3677	508	4984	290
4400	3855	533	5226	303
4600	4033	558	5468	317
4800	4212	582	5709	331
5000	4390	607	5951	345
5200	4568	632	6193	358
5400	4747	656	6435	372
5600	4925	681	6676	386
5800	5103	706	6918	400
6000	5282	730	7160	414
6200	5458	755	7399	427
6400	5634	779	7638	441
6600	5811	804	7877	455
6800	5987	828	8116	468
7000	6163	852	8355	482
7200	6342	877	8598	496
7400	6521	902	8840	510
7600	6700	927	9083	524
7800	6879	951	9326	538
8000	7058	976	9568	552
8200	7239	1001	9814	565
8400	7420	1026	10059	579
8600	7601	1051	10304	593
8800	7782	1076	10550	607
9000	7963	1101	10795	620
9200	8138	1126	11032	634
9400	8313	1150	11270	648
9600	8488	1174	11507	662
9800	8663	1198	11744	676
10000	8838	1222	11981	690